




# User's Manual

## TP850 Series

### Printer



## **Declare**

### **About Trademark**

Corporation names and product names are the registered trademarks or commodity names of the corporation.

- \* Jolimark is a registered trademark of Kong Yue Electronics & Information Industry (XIN HUI) LTD.
- \* EPSON and ESC/POS are the registered trademarks of Seiko Epson Corporation.
- \* Windows is a registered trademark of Microsoft Corporation.

## Warnings, Cautions, and Notes

Pay attention to the following promises when using this manual:

**Warning:**

*Warnings must be followed carefully to avoid bodily injury.*

**Caution:**

*Cautions must be observed to avoid damage to your equipment.*

**Note:**

*Notes contain important information and useful tips on the operation of your printer.*

## Important Safety Instructions

**Read all of these instructions carefully and thoroughly and save them for later reference. The unauthorized operation would lead to malfunction or accident. Manufacturers have no responsibilities for the problems which are led by unauthorized operations.**

1. Follow all warnings and instructions in the manual as well as marked on the product.
2. Don't touch the thermal print head with your hand at any moment to avoid the thermal head damaged.
3. Be careful the manual cutter when you are installing the paper.
4. Unplug this product from the power outlet before cleaning. Do not use the chemicals like alcohol to clean the printer. Use a damp cloth for cleaning.
5. Please don't use the printer near water.
6. Slots and opening on the cabinet and the back or bottom are provided for ventilation. To ensure reliable operation of the product and to protect it from overheating, do not block or cover these openings. And do not place the printer on a bed, sofa, rug or other similar surface in case of blocking the openings. This product should not be placed in a crowded environment unless proper ventilation is provided.
7. Make sure the printer is put on a stable surface and the surrounding is wide enough for paper load and eject.
8. Avoid using the same AC socket with other high-power electric appliances or the electric appliance device which will easily cause voltage fluctuation.
9. The whole computer system should be far away from the devices which may easily cause electromagnetic interference, for example, loudspeaker or wireless component.
10. Do not locate this product where the cord will be stepped on. When the cord or the plug is mangled, please stop using and get a new one replaced. Make sure the old one is far away from the printer, so it can avoid someone who does not know the inside story getting damaged.
11. This product should never be placed near or over a radiator or heat origin, and should avoid of direct sunshine.
12. Never push objects of any kind into this product though cabinet slots as they may touch dangerous voltage dots or short out parts.
13. Don't remove the printer's out-cover and repair the printer. When needed, call or take it to the professional.
14. Make sure the power is off before connecting or unplugging the power cord and the cables.
15. To ensure safety, please unplug this product prior to leave it unused for an extended period. The wall outlet you plan to connect to should be nearby and unobstructed.
16. Unplug this product from the power outlet and leave servicing to qualified service personnel under the following conditions:
  - A. When the power cord or plug is damaged or frayed.
  - B. If liquid has been spilled into the product.
  - C. If the product has been exposed to rain or water.
  - D. If the product does not operate normally when the operating instructions are followed.
  - E. If the product has been dropped or the cabinet has been damaged.
  - F. If the product exhibits a distinct change in performance, it indicates a need for service.

**Note: The contents of this manual are subject to change without notice.**

**\*All the parts of the printer can be recycled. When it is abandoned, we can call it back freely. Please contact us when you abandon it.**

**Note: In order to ensure the printer life, strictly prohibit printing full line and full black exceeding 2 CM.**

## Table of Contents

<b>Declare</b> .....	<b>i</b>
<b>Important Safety Instructions</b> .....	<b>iii</b>
<b>Chapter 1 Overview</b> .....	<b>1</b>
1.1 Features .....	1
1.2 Product Model Description .....	1
1.3 Main Parts of the Printer.....	1
<b>Chapter 2 Installing the Printer</b> .....	<b>3</b>
2.1 Unpacking and Checking .....	3
2.2 Removing the Protective Materials.....	3
2.3 Connecting to Your Computer or Other Equipment.....	3
2.3.1 <i>Connecting the Cash Drawer Cable</i> .....	3
2.3.2 <i>Connecting the Parallel Cable</i> .....	4
2.3.3 <i>Connecting the USB Cable</i> .....	4
2.3.4 <i>Connecting the Serial Cable</i> .....	5
2.3.5 <i>Connecting the Ethernet Cable</i> .....	5
2.4 Connecting the Power.....	6
2.5 Installing the Driver .....	7
2.5.1 <i>Auto-installing Way (Recommended)</i> .....	7
2.5.2 <i>Hand-operated Installing Way</i> .....	7
2.6 Selecting the Cutter.....	8
2.7 Installing the Bluetooth Interface Driver .....	9
2.8 Ethernet Settings.....	11
2.8.1 <i>Connecting the Printer</i> .....	12
2.8.2 <i>Setting IP Address</i> .....	12
2.9 Wi-Fi Setting of Jolimark Printer.....	14
2.9.1 <i>Connecting the Printer</i> .....	14
2.9.2 <i>Wi-Fi Parameters Description</i> .....	17
2.9.3 <i>Wi-Fi Interface Status Display and Parameters Reset</i> .....	28
2.10 Installing Printer Network Driver.....	28
<b>Chapter 3 Control Panel</b> .....	<b>35</b>
3.1 Control Panel .....	35
3.1.1 <i>LED</i> .....	35
3.1.2 <i>Function Button</i> .....	35
3.2 Self Test .....	35
3.3 Hex Dump Printing .....	35
3.4 Restoring Factory Default Setting .....	35
3.5 Online-aptitude Parameter Settings .....	36
<b>Chapter 4 Installing Paper</b> .....	<b>38</b>
4.1 Thermal Paper Installing Steps .....	38
<b>Chapter 5 Specification</b> .....	<b>40</b>

5.1 General .....	40
5.2 Interface .....	42
5.2.1 Cash Drawer Interface.....	42
5.2.2 Parallel Interface.....	42
5.2.3 USB Interface .....	43
5.2.4 Serial Interface .....	43
5.2.5 Ethernet Interface .....	45
5.2.6 Power Supply Inlet.....	45
<b>Chapter 6 Printer Maintenance .....</b>	<b>46</b>
6.1 Cleaning the Printer .....	46
6.2 Error Message on the Control Panel .....	46
6.3 Contact the Technical Service Center .....	46
<b>Chapter 7 Control Commands .....</b>	<b>47</b>
7.1 General .....	47
7.2 Explanation of terms .....	47
<b>Appendix Command List .....</b>	<b>60</b>

## Chapter 1 Overview

### 1.1 Features

TP850 printer is a high-speed thermal printer. It is a high-quality, high-reliability and low-noise POS printer without ribbon. It's small, easily-operated and can be widely used in ECR, PC-POS and BANK POS for printing a variety of receipts.

### 1.2 Product Model Description

In order to fulfill different requirements and operating circumstance, manufacturer develops TP850 series products which are high-speed thermal mini-printers.

According to different data ports (interfaces), TP850 series can be classified into different models: TP850, TP850U, TP850US, TP850UE, TP850USE, TP850UB, TP850W and TP850UW.

TP850 series printers are equipped with auto cutter, so that customer could select full cut or partial cut.

#### Interface:

TP850 series products are configured with cash drawer interface, you can choose one of the following data interfaces when purchasing this product:

- Parallel interface (TP850)
- USB interface (TP850U)
- USB interface + Serial interface (TP850US)
- USB interface + Ethernet interface (TP850UE)
- USB interface + Serial interface + Ethernet interface (TP850USE)
- USB interface + Bluetooth (TP850UB)
- Wi-Fi (TP850W)
- USB interface + Wi-Fi (TP850UW)

**Note:** Please contact the local dealer to change the interface if needed with added expense.

### 1.3 Main Parts of the Printer




Figure 1-1 Main parts of the printer




Figure 1-2 Interfaces on the back of the printer

**Note: Please take the specific interface as standard.**



## Chapter 2 Installing the Printer

### 2.1 Unpacking and Checking

Check the following items in the package, if any of these items is missing, please contact your dealer.




Figure 2-1 Packing list

**Note:** 1. Models with Bluetooth and Wi-Fi are not equipped with interface cable.  
2. Roll paper guide is equipped according to the necessity of the customers.

### 2.2 Removing the Protective Materials

1. Open the packing box, take out the printer.
2. Save all the original packing materials so that they can be used when transporting the printer in the future.

### 2.3 Connecting to Your Computer or Other Equipment

The printer is configured with a cash drawer interface and one data interface (you can select Parallel interface, USB interface, USB interface + Serial interface, USB interface + Ethernet interface, USB interface + Serial interface + Ethernet interface, USB interface + Bluetooth, Wi-Fi or USB interface + Wi-Fi). Please take the specific interface as standard. Connect the printer to your computer with the correct cable.

**Note:** Before connecting the cash drawer cable, parallel cable or serial cable, make sure that the power of the printer is turned off. Only after tightening the cable may you turn on the printer. Or else the printer may be damaged.

#### 2.3.1 Connecting the Cash Drawer Cable

Turn off the printer and plug one end of the cash drawer cable into the cash drawer interface of the printer and the other end to the cash drawer. (As shown in Figure 2-2)




Figure 2-2 Connecting the cash drawer cable

**Caution: Please use the appropriate cash drawer. Manufacturer will not honor warranty when using unauthorized cash drawer.**

### 2.3.2 Connecting the Parallel Cable

1. Make sure the computer and the printer are both turned off, plug the parallel cable to the parallel interface of the printer, Squeeze the wire clips on both sides and make the connector fixed. (As shown in Figure 2-3)




Figure 2-3 Connecting the parallel cable

2. Plug the other end of the cable to the computer. Tighten the screws on both sides and make the cable fixed.

### 2.3.3 Connecting the USB Cable

1. Plug the USB cable A end (flat shape) into the computer's USB interface.
2. Plug the USB cable B end (square shape) into the printer's USB interface. (As shown in Figure 2-4)

**Note: Please don't impact the plug after connecting USB cable.**




Figure 2-4 Connecting the USB cable

### 2.3.4 Connecting the Serial Cable

1. Make sure the computer and the printer are both turned off, plug the serial cable to the serial interface of the printer. Tighten the screws on both sides and make the cable fixed (as shown in Figure 2-5).




Figure 2-5 Connecting the serial cable

2. Plug the other end of the cable to the computer's serial interface. Tighten the screws on both sides and make the cable fixed

### 2.3.5 Connecting the Ethernet Cable

Plug the crystal end of the Ethernet cable (RJ-45) into the printer's Ethernet interface and the other end to the LAN (as shown in Figure 2-6).




Figure 2-6 Connecting the Ethernet cable

**Note:** Please refer to the *user's manual* for detailed instructions of network settings.

## 2.4 Connecting the Power

1. Make sure the printer is turned off. (The pressed down side on the switch with "O" mark denotes the printer is off)
2. Make sure the voltage of the electrical outlet matches that of the AC adapter.
3. Plug the AC adapter to the printer's power supply inlet.
4. Plug one end of power cord into the AC adapter, and then plug the other end of the power cord into the grounded electrical outlet.




Figure 2-7 Connecting the power

**Warning:** 1. If the rated voltage doesn't match the outlet voltage, contact your dealer for assistance. Do not plug the power cord to electrical outlet.

2. Please use the electrical outlet connecting the ground properly.

3. Please use the original AC adapter only. Manufacturers have no responsibilities for the problems which are led by using unauthorized AC adapter.

## 2.5 Installing the Driver

Please use the cable to connect computer with printer, then turn on the computer and the printer, put the driver CD into the CD-ROM. Install driver by the following ways:

### 2.5.1 Auto-installing Way (Recommended)

Double click the file "Setup.exe" in the driver disc, install driver by the guide.

**Note: Auto-installing way needs the operating systems of Windows2000 and above and the operating systems of Window 98/ME and below are not supported.**

### 2.5.2 Hand-operated Installing Way

**Note: This installing way is used for the people who have some knowledge on hand-operated installing and equipment application.**

#### 2.5.2.1 The Operating Systems of Windows 2000/XP/Vista/Win7

##### (1) The hand-operated installing steps of parallel interface or serial interface:

The following steps are used Windows XP as an example. There are slight differences among different operating systems. The installing way with other operating systems depends on the practical installing process.

- 1 Click "Start" → "Settings" → "Select Printers".
2. Click "Add Printer", then it pops up a window of "Add Printer Wizard", click "Next", then please read the select guide carefully, such as, select "Local printer" in the "Local or Network Printer" window, then click "Next".
3. A window of "Select a Printer Port" pops up, according to your requirement, select "LPT1: (Recommended Printer Port)" or serial interface, click "Next".
4. A window of "Install Printer Software" pops up, click "Have Disk...".
5. A window of "Install From Disk" pops up. Please according to the operating system environment, you should select the path as follows: CD-ROM → "Drivers" → "WIN2000 (XP-Vista-Win7)", click "Open", then click "OK" to return to the window of "Install Printer Software", click "Next".
6. Follow the guide and click "Next" gradually till the installation is finished.

##### (2) The hand-operated installing steps of USB interface:

The following steps are used Windows XP as an example. There are slight differences among different operating systems. The installing way with other operating systems depends on the practical installing process.

1. Connect with the USB cable and turn on both the computer and the printer. After the computer finds out new hardware, and a window of "Found New Hardware" pops up — "Welcome to the new hardware wizard".
2. Select the "Set from the list or specific position", then click "Next"
3. A window of "Please choose your search and installation options" pops up, choose "Don't search, I will choose the driver to install", click "Next".
4. A window of "Add Printer Wizard" pops up, click "Have Disk...".
5. A window of "Install From Disk" pops up. Please according to the operating system environment, you should select the path as follows: CD-ROM → "Drivers" → "WIN2000 (XP-Vista-Win7)", click "Open", then click "OK" to return to the window of "Add Printer Wizard", click "Next".
6. Follow the guide and click "Next" gradually till the installation is finished.

#### 2.5.2.2 The Operating System of Windows 8

**The hand-operated installing steps of parallel interface, serial interface or USB interface:**


1. Enter "Control Panel" → "Device and Printers".
2. Click "Add Printer", then a window of "Add Printer Wizard" pops up, then click "Next", select "Add Local printer Manually" in the "Local or Network Printer" window.
3. A window of "Select a Printer Port" pops up, according to your requirement, click "Use the Current Port", select "LPT1: (Printer Port)", serial interface or USB interface, click "Next".
4. A window of "Install Printer Driver" pops up, click "Have Disk...".
5. A window of "Install From Disk" pops up. Please according to the operating system environment, you should select the path as follows: CD-ROM → "Drivers" → "Windows 8", click "Open", then click "OK" to return to the window of "Install Printer Driver", click "Next".
6. Follow the guide and click "Next" gradually till the installation is finished.

## 2.6 Selecting the Cutter

Please install the driver following the setup description in the CD going along with the printer. What's more, you can use the TM-T88II, TM-T88III series driver from EPSON.

If you want to cut the paper after printing each page, please select "cut" or "no cut" in the "Paper Source" of "Paper/Quality" page after clicking the "Printing Preferences" button, which lies in the "General" page of the driver properties (as shown below).


**Note: if paper cut effect is the same whichever you select "full cut" or "partial cut" in the driver properties, it means that the cutter (the printer equipped with) can only carry out one kind of cut-methods.**



## 2.7 Installing the Bluetooth Interface Driver

**Note:** Select to install this driver according to the chosen model.

1. Choose the appropriate Bluetooth adapter, the operation system is Window XP or above which is with Bluetooth adapter driver.
2. Turn on the printer, search Bluetooth devices in Window XP system, and click "Add".



3. Tick off the option of "My device is set up and ready to be found." Click "Next" to continue.




4. Select the “TP850”, and then click “Next”.



5. Tick off the option of “Let me choose my own passkey” and enter “1234” as shown, then click “Next”.





6. Record the Outgoing COM port and click "Finish", then reboot the computer.



7. Set the printer driver print port as the outgoing port and the installation is finished.

**Note: Every Bluetooth device has its own address. Please reinstall it when replacing the Bluetooth device.**

## 2.8 Ethernet Settings

Please use Jolimark network setting software NetFinder to set the IP address for Jolimark Ethernet

interface network printers. NetFinder Software (NetFinder.exe) can be found in the CD or downloaded from [www.jolimark.com](http://www.jolimark.com)

**Note: The network printing function needs the operation systems of Windows2000 and above and the operation systems of Window 98/ME and below are not supported.**

## 2.8.1 Connecting the Printer


Power on the printer, connect with the Ethernet interface cable which has been connected to LAN, and look into the information of Ethernet LED to ensure the printer has entered the normal connection.

Orange LED	Green LED	Description
On	Blink	Online
Off	Off	Offline

## 2.8.2 Setting IP Address

### 1. Running NetFinder Software

Double click NetFinder.exe in the PC which connects the printer in the same LAN. The figure of the software is shown as follows:



Button description:


Exit — Exit from the software

Search — Search printers in the same LAN

Assign IP — Modify the IP address and other settings for the specified printer.

### 2. Searching the Printer

Click "Search" button in the main interface, the dialog box appearing will begin searching automatically and displays the status, listing a printer in the main interface if found. The time is counting down in the progress bar (10s in total) and the search will finish as soon as the time is over. If you need to go on searching, press "Search" button again.




If the printer connects correctly, the IP address can be found in a search period.

If the printer still can not be found out when the network connection is correct in the same network. Please check whether the network fire wall on the PC is open or not. If there is fire wall, please close it temporarily, open again after finish searching and setting the printer completely.

### 3. Setting Printer's IP Address

The printer's information is listed in the main interface, the left side of which is the model and description and the right are the IP address and MAC address. What's more, the assign mode (dynamic/static) is noted behind the IP address.




#### 1) Correlative description for IP address settings

In order to search and set printer's IP address conveniently for the first time, the factory default setting is DHCP mode which assigns IP address dynamically. If there is no DHCP server in the connected LAN but printer is set to DHCP mode, then it will use the internal pre-set address (IP: 10.0.0.1, Subnet Mask: 255.255.255.0) automatically.

It is suggested that printer's IP is set to static in actual usage, which can cut down the time when initializing the Ethernet interface as the printer is turned on and prevent IP conflicts (The dynamic address used in printer may conflict with another one). The network segment part of the IP address and Subnet Mask must be the same as those of PC connecting with a printer. For example, the address of working PC is 192.168.0.1/255.255.255.0 (IP/Subnet Mask), then which of printer should be set to 192.168.0.x/255.255.255.0 (x=2~254 and should avoid the occupied IP). It is not restricted for NetFinder to search printers in the same network but different segment parts (can not stride gateway). Relative glossary of IP address may refer to corresponding information.

## 2) Setting printer's IP address

Select the printer information to be modified (black frame appears), click "Assign IP" button. Set the IP in the dialog box appearing.



The image shows a dialog box titled "Assign IP Address". It contains three input fields for IP configuration: "IP:" with the value "192 . 168 . 7 . 65", "Subnet Mask:" with "255 . 255 . 248 . 0", and "Default Gateway:" with "255 . 255 . 255 . 255". To the right of these fields are three buttons: "OK", "Cancel", and "Default setting". Below the input fields, there are three checkboxes: "Use DHCP" (checked), "Reload Timer" (unchecked), and "Close this window on success" (checked). At the bottom, there is a progress bar and the text "10 seconds remaining".

Check the "Use DHCP" if needed to assign dynamic address, the settings above will be disabled automatically. Please make sure there is a DHCP server in the network, or the printer can not receive an effective IP address.

When to specify static address, uncheck "Use DHCP" and fill in "IP address", "Subnet Mask" and "Default Gateway". If there is no gateway in the network, fill 255.255.255.255 in the "Default gateway". "IP address" and "Subnet Mask" should obey the assigning rules of local LAN (Ethernet), please enquire the administrator of networks which the printer connects to for more details.

Click "OK" to send address setting information to the specified printer. Click "Cancel" if you abandon the modification.

Click "Search" in the main interface again to update printer information after modifying the printer's IP address and restarting the printer.

## 3) Record printer's IP address

Record the printer's IP address, which will be used in the section "Newly-install printer network driver" or "Upgrade-install printer network driver (setting driver's network port)".

## 2.9 Wi-Fi Setting of Jolimark Printer

### 2.9.1 Connecting the Printer

TP830 is taken as an example to respectively describe the connection of Windows, Android and iOS operation systems. Please make the connection according to the operating guide of the current system, and skip to the next chapter "**Wi-Fi Parameters Description**" when the connection is successful.

## (1) Connecting to the equipment in Windows

Take Windows XP operating system as an example to show how to connect the printer with the equipment in Windows system.

1. Turn on the printer and make sure the printer is in normal working condition. Start the operation 30 seconds after the printer is on.
2. Right click "My Network Places", and then click "Properties" to find the "Local Area Connection 2". Double click it and the window of "Wireless Network Connection" pops up, select and double click the corresponding printer Wi-Fi name. The printer Wi-Fi default name is composed of "the printer model+6 numbers and letters" (as shown in Figure 1)




Figure 1

## (2) Connecting to the equipment in Android

Take the mobile phone of Android 4.4 as an example to show how to connect the printer with the equipment in Android.

1. Turn on the printer and make sure the printer is in normal working condition. Start the operation 30 seconds after the printer is on.
2. Click "Settings" and the interface pops up. Select the "WLAN" function to "ON", then click the printer Wi-Fi searched by the mobile phone to connect. The printer Wi-Fi default name is composed of "the printer model+6 numbers and letters" (as shown in Figure 2).




Figure 2

### (3) Connecting to the equipment in iOS

Take the mobile phone of iOS 8.1 as an example to show how to connect the printer with the equipment in iOS.

1. Turn on the printer; make sure the printer is in normal working condition. Start the operation 30 seconds after the printer is on.
2. Click "Settings" and the interface pops up. Select the "WLAN" function to "ON", then click the printer Wi-Fi searched by the mobile phone to connect. The printer Wi-Fi default name is composed of "the printer model+6 numbers and letters" (as shown in Figure 3).






Figure 3

## 2.9.2 Wi-Fi Parameters Description

After connecting the equipment with the printer through wireless network, please import <http://10.10.10.1> in the browser address bar and enter, then the setting interface pops up. The display style of setting interface may differ in different systems, but the parameter items are the same. Take Windows XP as an example in the following, as shown in Figure 4.



The screenshot displays the configuration page of a TP850 device. At the top, there is a header bar with a menu icon. Below it, the 'F/W Version' is 1.0.306, dated Dec 5 2014. The 'Select Language' dropdown is set to 'English', and an 'Apply' button is visible. The 'Wireless Settings' section includes fields for BSSID (CC:D2:9B:00:00:52), Network Name (SSID) (TP830\_000052), IP Address (10.10.10.1), Subnet Mask (255.255.255.0), and Security Mode (Disable). The 'AP Client' section includes fields for BSSID (CC:D2:9B:00:00:53), Channel (Auto), SSID (empty), Security Mode (OPEN), Encrypt Type (None), and Address Assignment (DHCP (Auto config)).

F/W Version	1.0.306 Dec 5 2014
Select Language	English
<input type="button" value="Apply"/>	
<b>Wireless Settings</b>	
BSSID	CC:D2:9B:00:00:52
Network Name(SSID)	TP830_000052
IP Address	10.10.10.1
Subnet Mask	255.255.255.0
Security Mode	Disable
<b>AP Client</b>	
BSSID	CC:D2:9B:00:00:53
Channel	Auto
SSID	
Security Mode	OPEN
Encrypt Type	None
Address Assignment	DHCP (Auto config)

Figure 4

You can select Simple Chinese, Traditional Chinese and English in the “Select Language” and the default language is English. When you need to change the language, just select the language you need in the “Select Language” and then click “Apply” (as shown in Figure 5).

The figure consists of two screenshots. The top screenshot shows the 'Select Language' dropdown menu open, displaying three options: '简体中文 (Simple Chinese)', 'English', and '繁體中文 (Traditional Chinese)'. The bottom screenshot shows the 'Select Language' dropdown set to '简体中文 (Simple Chinese)', with the 'Apply' button circled in red to indicate the next step.

F/W Version	1.0.306 Dec 5 2014
Select Language	简体中文 (Simple Chinese)
<input type="button" value="Apply"/>	

F/W Version	1.0.306 Dec 5 2014
Select Language	简体中文 (Simple Chinese)
<input type="button" value="Apply"/>	

Figure 5



### (1) Printer-equipment connected printing

Printer-equipment connected printing is a way of printing which uses printer as the hotspot and connects the wireless equipment for printing.

“Wireless Settings” is the relevant setting parameter when the printer is as the hotspot (as shown in Figure 6). In the printer-equipment connected printing mode, the parameters of the wireless equipment must match that of the printer so as to make the communication successful. Please record the relevant parameters and input them in the wireless equipment correctly.

After you finish resetting the parameters in the setting column, click “Apply” on the upper side of “Update Firmware”. Then the countdown interface of saving the modification appears and the wireless equipment can conduct communications with the printer as soon as the countdown is over.

Wireless Settings	
BSSID	CC:D2:9B:00:00:52
Network Name(SSID)	TP830_000052
IP Address	10.10.10.1
Subnet Mask	255.255.255.0
Security Mode	Disable
AP Client	
BSSID	CC:D2:9B:00:00:53
Channel	Auto
SSID	
Security Mode	OPEN
Encrypt Type	None
Address Assignment	DHCP (Auto config)
IP Address	
Subnet Mask	
<input type="button" value="Apply"/>	
Update Firmware	
Location:	<input type="text"/> <input type="button" value="Browse..."/>

Figure 6

#### Description in “Wireless Settings”

**BSSID:** The address of the printer wireless card in the “Wireless Settings”, which is the MAC address (Valid when it's in printer-equipment connected printing).

**Network name (SSID):** The network name of the printer wireless card. You can modify it if necessary, but you have to connect the network again after modifying.

**IP Address:** The IP address of the printer wireless card. You can modify it if necessary, but you need to enter the browser with the new IP after modifying.

**Subnet Mask:** The subnet mask of the printer wireless card. You can modify it if necessary.

**Security Mode:** The security mode of the printer wireless card. You can modify it if necessary.

If the connection between printer and computer is exceptional, please restart the printer or modify "Channel" in "AP Client".

## (2) AP connected printing

AP connected printing is a way of printing which connects the printer with the wireless equipment by the outer hotspot.

"AP Client" (as shown in Figure 7) includes the setting parameters of AP connection. Please fill in the information of current outer hotspot in the corresponding place. The parameters of the printer should match that of the current outer hotspot so as to make the communication successful. Please input them correctly.

AP Client	
BSSID	CC:D2:9B:00:00:53
Channel	Auto ▼
SSID	<input type="text"/>
Security Mode	OPEN ▼
Encrypt Type	None ▼
Address Assignment	DHCP (Auto config) ▼
IP Address	<input type="text"/>
Subnet Mask	<input type="text"/>
<input type="button" value="Apply"/>	

Figure 7

### Description in "AP Client"

**BSSID:** The address of the printer wireless card in "AP Client", which is the MAC address. (Valid when it's in AP connected printing)

**Channel:** Select the corresponding channel according to the hotspot setting (Automatic is recommended).

**SSID:** The Wi-Fi name of the current hotspot.

**Security mode:** Select the corresponding security mode according to the hotspot setting.

**Encrypt type:** Select the corresponding encrypt type according to the hotspot setting.

### Acquiring and Setting the Security Mode and Encrypt Type

There are three ways to acquire security mode and encrypt type:

- (1) Get the security mode and encrypt type according to the corresponding network information given by the network administrator
- (2) Find them by entering the router of hotspot with the administrator's account.
- (3) Find them through Windows operating system and the steps are shown below (Take WIN XP as an example):

- ① Right click "My Network Places", and click "Properties", then double click "Local Area Connection 2" (as shown in Figure 8).




Figure 8

- ② The dialog box "Wireless Network Connection Status" pops up, then click "Properties" (as shown in Figure 9).




Figure 9

- ③ When the dialog box pops up, click “Wireless Networks” on the upper side of the dialog box (as shown in Figure 10).




Figure 10

- ④ Select the current wireless network name in “Preferred networks” and then click “Properties” ( as shown in Figure 11).




Figure 11

- ⑤ When the window of "Properties" pops up, find out the security mode and encrypt type in "Wireless network key" (as shown in Figure 12).




Figure 12

- ⑥ Close the windows in turn, then the dialog box "Local Area Connection 2 Status" pops up according to the operation of step ①, click "View Wireless Networks" (as shown in Figure 13). When the window of "Wireless Network Connection" pops up, double click the current hotspot and the connection will be disconnected (as shown in Figure 14).




Figure 13

The current Wi-Fi hotspot of this example.




Figure 14

The setting of Security Mode and Encrypt Type

Refer to **“Connecting the Printer”**, connect the wireless equipment with the printer and select the parameters acquired by the above steps in the “Security Mode” and “Encrypt Type” of the **“AP Client”**.

**Pass Phrase:** The password of the hotspot

**Address Assignment:** It includes “DHCP (Auto config)” and “Static (Assigned IP)”. You can select the corresponding assignment way according to your need. When selecting “DHCP (Auto config)”, the IP Address and Subnet Mask can be acquired automatically (Click “Apply” and the system will assign automatically), and there is no need to set manually (as shown in Figure 15).



AP Client	
BSSID	CC:D2:9B:00:00:53
Channel	1
SSID	Jolimark
Security Mode	WPA2PSK
Encrypt Type	AES
Pass Phrase	••••••••
Address Assignment	DHCP (Auto config)
IP Address	192.168.43.129
Subnet Mask	255.255.255.0
<input type="button" value="Apply"/>	

Figure 15

**Note:** The green handshaking mark on the right side of the SSID column denotes the connection between the printer and the outer Wi-Fi hotspot is successful.

**IP Address:** Set the IP address of the printer wireless card and the IP address should be in the same segment with the wireless networks you are using.

**Subnet mask:** Set the subnet mask of the printer wireless card and the subnet mask should be the same with that of the wireless networks you are using.

Click “Apply” after all the parameters are set, then the countdown interface appears. When the time is over, disconnect the computer with the printer and connect the computer with the outer hotspot.

**Update Firmware:** Upgrade the wireless module of the printer (as shown in Figure 16), and you can neglect it if there is no need to upgrade.

Update Firmware	
Location:	<input type="text"/> <input type="button" value="Browse..."/>
<p style="color: red;">It takes about 1 minute to upload and upgrade flash and be patient please. Caution! A corrupted file will hang up the system.</p>	
<input type="button" value="Apply"/>	

Figure 16

## 2.9.3 Wi-Fi Interface Status Display and Parameters Reset

Wi-Fi interface is equipped with the “RESET button (Wi-Fi RESET)” and “LED indicator”.

Turn on the printer, the Wi-Fi LED blinks fast, which denotes the interface is on the ON status. 30 seconds later, the Wi-Fi LED blinks slowly, which denotes the Wi-Fi interface is in normal working condition.

If user needs to restore the Wi-Fi parameters to factory default setting; just press the Wi-Fi RESET button to do it in a quick way. The method is as below:

1. Turn on the printer, wait for a few seconds until the Wi-Fi LED blinks slowly, and then press down the Wi-Fi RESET button for 2 seconds. Loosen the button and the LED blinks twice fast then blinks slowly again.
2. Reboot the printer and the factory default settings have been restored.

## 2.10 Installing Printer Network Driver


The ways of installing network driver are classified into Newly-install way and Upgrade-install way according to whether the PC is installed the printer driver or not.

If the printer driver hasn't been installed on the PC, adopt newly-install way whose steps are shown in “Newly-install printer network driver”.

If the printer driver has been installed on the PC, adopt Upgrade-install way whose steps are shown in “Upgrade-install printer network driver” (Setting driver's network port).

### 1. Newly-install printer network driver

- 1) Click “Start” → “Settings” → “Select Printers”.
- 2) Click “Add printer”, then a window of “Add Printer Wizard” pops up, click “Next”.
- 3) A window of “Add Printer Wizard” pops up, select “Local printer” in the “Local or Network Printer” window, and then click “Next”.
- 4) A window of “Select the Printer port” pops up, select “Create a new port”, and then select “Standard TCP/IP Port” in the port and click “Next”.



- 5) A window of “Add standard TCP/IP Printer Port Wizard” pops up, click “Next”.

- 6) A window of "Add Port" pops up, enter the IP address reported by the "Setting printer's IP address" in the "Printer Name or IP Address" column. Take IP address "192.168.0.240" for example as the figure shown below. "Port Name" is created automatically after finishing filling in IP address. Click "Next".

- 7) A window of "Additional Port Information Required" pops up, select "Custom" in the "Device Type", then click "Settings".

- 8) A window of "Port Settings" pops up. Affirm that "Port Name" and "Printer Name or IP Address" are correct, "Protocol" is "RAW" and "Port Number" is "9100", click "OK".

**Configure Standard TCP/IP Port Monitor**

**Port Settings**

Port Name: IP\_192.168.0.240

Printer Name or IP Address: 192.168.0.240

Protocol: ☒ Raw ☐ LPR

**Raw Settings**

Port Number: 9100

**LPR Settings**

Queue Name:

☐ LPR Byte Counting Enabled

☐ SNMP Status Enabled

Community Name: public

SNMP Device Index: 1


OK Cancel

- 9) Return to "Additional Port Information Required", click "Next".
- 10) A window of "Completing the Add Standard TCP/IP Printer Port Wizard" pops up, click "Finish".
- 11) In the window of "Install Printer Software", click "Have Disk".
- 12) A window of "Install From Disk" pops up. Please according to the operating system environment, such as Windows 2000/XP/Vista/Win7 operating system you should select the path as follows: CD-ROM → "Drivers" → "WIN2000 (XP-Vista-Win7)", click "Open", then click "OK" to return to the window of "Install Printer Software", click "Next".
- 13) Follow the guide and click "Next" gradually till the installation is finished. At this time, printer network driver is installed completely.


## 2. Upgrade-install printer network driver (setting driver's network port)

If PC has installed the printer's driver, set driver's network port to carry out network printing. The concrete steps are shown below:

- 1) Click "Start" → "Settings" → "Select Printers".
- 2) Right click TP850 driver, click "Properties" on the window popping up.
- 3) A window of "Properties" pops up; click "Ports" and "Add Port".




4) A window of "Printer Ports" pops up, select "Standard TCP/IP Port", click "New Port".




5) A window of "Add Standard TCP/IP Printer Port Wizard" pops up, click "Next".


6) A window of "Add Port" pops up, import the IP address reported by the "Setting printer's IP address" in the "Printer name or IP address" column. Take IP address "192.168.0.240" for example. "Port Name" is created automatically after finishing filling in IP address. Click "Next".



- 7) A window of "Additional Port Information Required" pops up, select "Custom" in the "Device Type", then click "Settings".




- 8) A window of "Port Settings" pops up. Affirm that "Port Name" and "Printer Name or IP Address" are correct, "Protocol" is "RAW" and "Port Number" is "9100", click "OK".




The "Configure Standard TCP/IP Port Monitor" dialog box is shown. It has a title bar with a question mark and a close button. The "Port Settings" tab is selected. The "Port Name" field contains "IP\_192.168.0.240". The "Printer Name or IP Address" field contains "192.168.0.240". The "Protocol" section has two radio buttons: "Raw" (selected) and "LPR". The "Raw Settings" section has a "Port Number" field containing "9100". The "LPR Settings" section has a "Queue Name" field (empty) and a checkbox "LPR Byte Counting Enabled" (unchecked). The "SNMP Status Enabled" checkbox is also unchecked. Below it, the "Community Name" field contains "public" and the "SNMP Device Index" field contains "1". At the bottom are "OK" and "Cancel" buttons.

- 9) Return to "Additional Port Information Required", click "Next".
- 10) A window of "Completing the Add Standard TCP/IP Printer Port Wizard" pops up, click "Finish".
- 11) Return to "Printer Ports", click "Close".



The "Printer Ports" dialog box is shown. It has a title bar with a question mark and a close button. The "Available port types:" section contains a list box with three items: "Local Port", "Standard TCP/IP Port" (highlighted), and "ThinPrint Print Port Monitor for VMWare". At the bottom are three buttons: "New Port Type...", "New Port...", and "Close".

- 12) Return to "Properties", make sure the network port is selected, click "Apply", and then click "Close". Thus, printer's network port setting is finished.





## Chapter 3 Control Panel

### 3.1 Control Panel

There are three LEDs and one button on the control panel. (As Figure 3-1 shown)



Figure 3-1 Control Panel

#### 3.1.1 LED

LED	Description
POWER (Green)	Denotes whether the printer's power supply is connected or not. The LED is on when the power is connected.
ERROR (Red)	Denotes printer's status. The LED is on when the malfunction appears.
PAPER OUT (Red)	Denotes printer's paper status. The LED is on when paper out occurs.

**Note:** Refer to “Error message on the control panel” for detailed information about LED malfunctions in this *user's manual*.

#### 3.1.2 Function Button

Button	Description
<b>【FEED】</b>	<b>【FEED】</b> controls paper feeding, you can enable or disable the function with a command. When enabled, the paper will be fed continuously if you hold on pressing it, or stop if you loosen it.

### 3.2 Self Test

Self-test printing is to check if the printer is working properly. If the printer printouts the self-test content normally, it denotes that there is nothing wrong with the printer except for the interface which connects to the computer. Otherwise, the printer should be repaired.

The printer will print out self-test information such as the software version and interface etc.

Hold on pressing the **FEED** button and turn on the printer while the printer cover is closed, the ERROR LED blinks once with one beep (if beeper is installed in the printer). Loosen the button, then the printer prints out the self-test information.

### 3.3 Hex Dump Printing

This function is to check whether the connection between the printer and the computer or the terminal device works properly or not. The method is that hold on pressing the **FEED** button and turn on the printer, the ERROR LED blinks twice with two beeps, then loosen the button. Turn off the printer and restart it to exit this print mode.

### 3.4 Restoring Factory Default Setting

The function is to clear the settings stored in the printer and to restore the factory default settings for correlative parameters.

The method is that hold on pressing the **FEED** button and turn on the printer, the ERROR LED blinks five times with five beeps, then loosen the button, at this time, the function takes effect and turn off the

printer.

### 3.5 Online-aptitude Parameter Settings

TP850 supports the function of parameter settings, which can be set in the PC with the driver installed in.

The concrete setting steps are shown as follows:

1. Make sure that the computer and the printer are connected with the USB cable and both the computer and the printer are turned on, the printer should be in normal working condition as well.
2. Under the operating system of WIN 2000/WIN XP/VISTA/WIN 7, click "Start" → "Settings" → "Printers", and open the window of "Printers".

Under the operating system of Windows 8, click "Desktop" in the main panel firstly, and then double click "Control panel" after entering the window of "Desktop", click "Hardware and Sound" to find "Devices and printers", at last, open the window of "Devices and printers".


3. Right click "TP850" in the window of "Printers", and then select "Properties".
4. Click "Printer settings" in the "Properties" page and open the window of "Printer settings".



5. In the window of "Parameter settings", each item on the left of the menu setup item is the parameter icon. The items on the upper right are the parameters and the items on the bottom right are the current settings. The computer will load the printer's current setting automatically when you open the parameter setting window. The current setting will be blank if the printer is offline or the printer port is set incorrectly. Then you need to set the printer to online mode or set the printer port correctly.



6. To set parameter, first click the parameter icon, then open the parameter setting window. There are Parameter options, Explanation and Control buttons in the window. Select the corresponding parameter and click "Set"; the printer will change the setting at the time it receives the command. Click "Cancel" to return to the upper window and click "Default" to display the default settings of this menu items.



7. If you want to set several parameters, please refer to the previous point and set the parameter one by one.
8. When the setting is finished, click "Set" to exit the window of "Properties".
9. Restart the printer and the new settings take effect.

## Chapter 4 Installing Paper

The printer can use the paper with the width of  $79.5\pm0.5\text{mm}$  and  $57.5\pm0.5\text{mm}$  conveniently. How to install the paper will be explained in details in this chapter.

### 4.1 Thermal Paper Installing Steps

**Caution:** 1. Don't touch the thermal print head after printing to avoid getting hurt.  
2. Don't pull the paper out directly with your hand.

1. Press the cover-open button to open the upper cover. If you want to use 57.5mm paper to print, you must install the roll paper guide firstly.




Figure 4-1 Opening the printer cover




Figure 4-2 Installing the roll paper guide (Optional)

2. Place the roll paper into the paper holder and pull out a small amount of paper.




Figure 4-3 The direction of installing paper

**Note: Paper head should be placed down and pulled towards the paper-input slot, but not the opposite.**

- Put the paper head on the printer as shown below and close the upper cover.




Figure 4-4 Pull out the paper head and close the cover

**Note: After installing the paper, if PAPER OUT LED and ERROR LED still light, or the printer makes strange noise when feeding paper, please open the cover and re-close it tightly.**

## Chapter 5 Specification

### 5.1 General

Item	Description	
Printing method	Thermal line printing	
Paper feed mode	Unidirectional with friction feed	
Paper eject direction	Eject from top	
Dot density	640 dots/line (203×203 DPI)	
Printing width	Max:80 mm, 640 dots	
Print speed	Max: 300 mm/s	
Paper feed speed	Max: 300 mm/s	
Line spacing	3.75 mm	
Print head life	150 Km, 1X10 <sup>8</sup> pulse	<b>Note: The instructions are all under the laboratorial measurements with specified paper.</b>
Cutter life	1.5 million cut	
Paper thickness	0.065 ~ 0.12 mm	
Paper specification	Thermal roll paper model	TF50KS-E (Japan paper co.ltd) AF50KS-E (JUJO THERMAL)
	Width: 79.5 ±0.5 mm; 57.5 ± 0.5 mm	
	Weight: 53 ~ 80 g/m <sup>2</sup>	
	Maximum diameter: Φ83 mm	
	Paper thickness: 0.065 ~ 0.12 mm	
	<b>Note: The inner diameter of paper shaft is Φ12 mm and the outer diameter of paper shaft is Φ18 mm.</b>	
Character set	ASCII: 13 international character sets	
Interface	This printer can be equipped with the following interfaces: Parallel interface: Centronics USB interface: 2.0 Full-Speed USB interface (2.0 Full-Speed) + Serial interface (RS-232C, DB9) USB interface (2.0 Full-Speed) + Ethernet interface (10/100Base-T) USB interface (2.0 Full-Speed) + Serial interface(RS-232C, DB9) + Ethernet interface (10/100Base-T) USB interface (micro) + Bluetooth Wi-Fi (802.11b/g/n) USB interface (micro) + Wi-Fi (802.11b/g/n)  <b>Note: 1. Only one of the data interfaces is supplied when leaving the factory. 2. Please take the specific interface as standard.</b>	
Cash drawer interface	RJ-11, 24V (DC)/1A	
Especial function	Automatic cutter, Online parameter settings, Online software upgrade	
Input buffer	4 MB	
Control command	ESC/POS Emulation  Character printing command: Support ANK characters, user-defined characters and enlarged printing of Chinese characters 1~8 times, can adjust character line spacing	

	Dot image printing command: Support different densities dot images and downloading image printing, can save NV bitmap without electricity (Can save LOGO for long)	
	Bar code	Linear bar code: UPC-A, UPC-E, EAN-13, EAN-8, CODE39, CODE128, ITF-25, CODABAR
		Two-dimension code: PDF417, QR CODE
Power Supply (AC adapter)	IN	Voltage: 100 ~ 240 V (AC)
		Frequency: 50Hz/60Hz
	OUT	Voltage: 24 V (DC)
		Current: 2.5 A
Power input	Parameters	Input voltage: 24 V (DC)
		Current: 2.5 A
		<b>Warning: Please use the original AC adapter only. Manufacturers have no responsibilities for the problems which are led by using unauthorized AC adapter.</b>
Environmental conditions	Operating environment	Temperature: 5 ~ 35°C
		Humidity: 25 ~ 80%RH (No condensation)
	Storage environment	Temperature: -40 ~ 55°C
		Humidity: ≤93%RH (40°C, no condensation)
Weight	Approx.1.45 kg	
Noise	<38 dB (A) (ISO7779 standard)	
Physical dimensions	148 mm (width) × 207 mm (depth) × 135 mm (height)	
Power consumption	① Operating: 40 W; ② Standby: Approximately 3.5 W	
	<b>Note: Only when the product is unconnected with outer power supply, can it achieve zero energy consumption state.</b>	
Code page	77 kinds	
Control panel	1 key and 3 LED indicators	
Paper type	Thermal roll paper	

**Note: All the technical instructions in this user's manual are the laboratorial measurements which are achieved under national standard store and work environment (room temperature), the measuring paper accords with the specification in this user's manual.**

**Note: In order to ensure the printer life, strictly prohibit printing full line and full black exceeding 2 CM.**

## 5.2 Interface

The printer is configured with one cash drawer interface and one data interface (you can select Parallel interface, USB interface, USB interface + Serial interface, USB interface + Ethernet interface, USB interface + Serial interface + Ethernet interface, USB interface + Bluetooth, Wi-Fi or USB interface + Wi-Fi). Connect the computer with the suitable cable.

### 5.2.1 Cash Drawer Interface

The cash drawer interface is RJ-11 interface, shown as below.




Figure 5-1 Cash drawer interface

The pin definition of cash drawer interface is shown as Table A-1:

Pin Number	Signal	Direction
1	Frame GND	---
2	Cash Drawer drive signal	OUT
3	Cash Drawer Open/closed signal	IN
4	24V (DC)	OUT
5	Cash Drawer drive signal	OUT
6	Cash Drawer Open/closed signal ground	---
Drive current ≤ 24V/1A		

Table A-1 Pin definition of the cash drawer interface

**Note:** Please use the cash drawer that meets the specification mentioned above. Manufacturer will not honor warranty when using unauthorized cash drawer.

### 5.2.2 Parallel Interface

TP850 printer's parallel interface is compatible with Centronics protocol, supporting BUSY/ACK handshaking protocol and the interface connector is the 36 PIN Centronics type.




Figure 5-2 Parallel interface

Signal definition of each pin of 36PIN parallel interface is shown as the Table A-2 below:

Pin Number	Signal	Direction	Description
1	/STB	IN	Trigger in low level, load the data in rising edge.
2	DATA1	IN	These signals respectively represent the parallel data from the first bit to the eighth. "1" means high level, while "0" in logic means low level.
3	DATA2	IN	
4	DATA3	IN	
5	DATA4	IN	



6	DATA5	IN	
7	DATA6	IN	
8	DATA7	IN	
9	DATA8	IN	
10	/ACK	OUT	Acknowledge pulse, Low level means that printer is ready to receive data.
11	BUSY	OUT	High level means printer is too busy to receive data.
12	PE	OUT	High level means that paper is out.
13	SEL	OUT	"High" level is pulled up by resistor.
32	/ERR	OUT	Low level means the printer is in error status.
14, 15, 17, 18, 34, 36	NC	---	NC
16, 19~30, 33	GND	---	GND, "0" level in logic

Table A-2 Pin definition of 36PIN parallel interface

**Note:** ① "IN" means input to the printer, "OUT" means output from the printer.  
 ② The logical level of signal is TTL level.

Time sequence of parallel interface signal is shown as Figure 5-3.




Figure 5-3 Time sequence of parallel interface signal

### 5.2.3 USB Interface

USB interface is the 2.0 Full-Speed version.




Figure 5-4 USB interface

Contact number	Signal name	Color
1	VBUS	Red
2	D-	White
3	D+	Green
4	GND	Black

### 5.2.4 Serial Interface

TP850 printer's serial interface is compatible with RS-232C protocol, supporting RTS/CTS and XON/XOFF handshaking protocol. Its connector is a DB-9 type connector and pin number of serial

interface connector is shown as below.




Figure 5-5 Pin number of serial interface connector

Table A-3: Signal definition of the serial interface pin

Pin number	Signal	From	Description
2	RXD	Host	Receive data from Host
3	TXD	Printer	Send control code X-ON/X-OFF and data to the Host
8	CTS	Printer	"MARK" state means printer is too busy to receive data; "SPACE" means printer is ready to receive data.
5	GND	—	Signal GND
4	DTR	Printer	Data terminal is ready.

Table A-3: Signal definition of the serial interface pin

**Note:** ① "From" means the source where signal comes out.  
② The logical level of signal is EIA level.

The default settings of baud rate and data configuration in serial connecting way are 9600bps, 8 data bits, parity check disabled and 1 stop bit.

TP850 printer's serial interface can be connected with the standard RS-232C connector. When connecting with a PC, the connecting picture is shown as Figure 5-6. While connecting with an IBM PC or a compatible PC, you can connect the cable as shown in Figure 5-7.

The connection of the serial interface:




Figure 5-6 The connection figure of host 9 PIN and printer




Figure 5-7 The connection figure of host 25 PIN and printer

### 5.2.5 Ethernet Interface

Ethernet interface of 10/100 Base-T can be connected to 10/100M Ethernet.




Figure 5-8 Ethernet interface

### 5.2.6 Power Supply Inlet

The TP850 printer connects with a 24V±10% and 2.5A AC adapter. The power supply inlet is shown as Figure 5-9.




Figure 5-9 Power supply inlet

## Chapter 6 Printer Maintenance

### 6.1 Cleaning the Printer

#### ■ Cleaning periodically and the cleaning tool

Periodical cleaning: every 3 months or every 300 working hours once

Cleaning tool: dry cloth (please use soft cloth to clean metal parts)

#### ■ Cleaning the spare parts

Clean the oily spare parts of the printer with dry cloth.

#### ■ Cleaning the paper feed path

Wipe off the wasted paper and clean the dirt and dust.

#### ■ Cleaning the photoelectric sensor part

As the paper sensor is a correlation photoelectric sensor. You should clean the parts periodically.

Clean the shield of the sensor every three months.

**Note:** 1. Turn off the printer and pull out the power cord before cleaning.

2. Print head and the surrounding part may be high temperature after using. Please avoid cleaning it at the moment.

3. Don't use hard cloth or combustible solvent to clean the printer.

### 6.2 Error Message on the Control Panel

When the malfunction occurs, the printer will be off-line and give an alarm through LEDs as shown below:

ERROR LED	PAPER OUT LED	Reason	Solution
Blink fast	Off	Auto cutter error	Restart the printer and the auto-cutter will return to the home position automatically. If the problem is still unsolved, please contact the Customer Service Center for maintenance.
On	Off	Cover is open	Close the cover and press it tightly.
On	On	Paper out	Reinstall the paper.
Blink	Off	Print head overheated	Resume working after it cools.

### 6.3 Contact the Technical Service Center

If malfunction occurs and you cannot solve the problem through the operation shown in 6.2, the components of the printer are damaged during using or you need to buy some consumables, please contact the authorized technical service centre.

## Chapter 7 Control Commands

### 7.1 General

The commands TP850 supplies are based on ESC/POS.

The format is described as follows:

Command	Function
Format:	ASCII: Indicates the ASCII equivalents
	Decimal: Indicates the decimal equivalents
	Hex: Written in hexadecimal code
Description:	The function and using instruction of that command
Example:	Some examples will be listed for easier understanding

### 7.2 Explanation of terms

BEL	Beep once
-----	-----------

Format:	ASCII:	BEL
	Decimal:	7
	Hex:	07

Description:

Beep once in the unit of 50 milliseconds

HT	Horizontal tab
----	----------------

Format:	ASCII:	HT
	Decimal:	9
	Hex:	09

Description:

Move the print position to the next horizontal tab position

LF	Print and line feed
----	---------------------

Format:	ASCII:	LF
	Decimal:	10
	Hex:	0A

Description:

Print the data in the input buffer and feed one line. If the line input buffer is empty, then it only feeds one line without printing.

FF	Print and Feed to the next black mark position
----	--

Format:	ASCII:	FF
	Decimal:	12
	Hex:	0C

Description:

Print the data in the print buffer and feeds paper to the next black mark position when black mark takes effect.

DLE EOT n	Status transmission
-----------	---------------------

Format:	ASCII:	DLE	EOT	n
	Decimal:	16	4	n
	Hex:	10	04	n

Description:

Transmit the selected printer status in serial interface,  $1 \leq n \leq 4$ ; this command is still valid even in error or off-line status.

n=1: Transmit print status  
 n=2: Transmit off-line status  
 n=3: Transmit error status  
 n=4: Transmit paper sensor status

ESC BEL n1 n2 Beep for appointment

Format:	ASCII:	ESC	BEL	n1	n2	n3
	Decimal:	27	7	n1	n2	n3
	Hex:	1B	07	n1	n2	n3

Description:

N1 specifies the length of beeping time, n2 specifies the length of intermission time and n3 is the beeping times. The unit of n1 and n2 is 100 milliseconds.

ESC SP Set right-side character spacing

Format:	ASCII:	ESC	SP	n
	Decimal:	27	32	n
	Hex:	1B	20	n

Description:

Set the right-side spacing of the character to n\*(horizontal or vertical minimal unit) n=0~255.

Horizontal or vertical minimal unit is specified by GS P command.

ESC ! Set character print mode

Format:	ASCII:	ESC	!	n
	Decimal:	27	33	n
	Hex:	1B	21	n

Description:

“ESC ! n” is the integrated setting command for character printing mode, n=0~255.

The significations of n are shown below.

Bit	Value	Function
0	0	Character A
	1	Character B
1, 2	-- -- --	Not defined
3	0	Emphasize mode not selected
	1	Emphasize mode selected
4	0	Double-height not selected
	1	Double-height selected
5	0	Double-width not selected
	1	Double-width selected
6	-- -- --	Not defined
7	0	Underline mode not selected
	1	Underline mode selected

ESC \$ Set absolute print position

Format:	ASCII:	ESC	\$	nL	nH
	Decimal:	27	36	nL	nH
	Hex:	1B	24	nL	nH

Description:

Set the distance from the beginning of the line to the print position. The distance is (nL+nH\*256)\* (horizontal or vertical minimal unit). nL, nH=0~255.

Horizontal or vertical minimal unit are specified by GS P command.

ESC %		Select/cancel user-defined characters set			
Format:	ASCII:	ESC	%	n	
	Decimal:	27	37	n	
	Hex:	1B	25	n	

Description:

n=1, Select the user-defined characters set; n=0, Select inner characters set.

Default: n=0

ESC &		Define user-defined characters					
Format:	ASCII:	ESC	&	y	c1	c2	[x1 d1..d(y*x1)] [xk d1..d(y*xk)]
	Decimal:	27	38	y	c1	c2	[x1 d1..d(y*x1)] [xk d1..d(y*xk)]
	Hex:	1B	26	y	c1	c2	[x1 d1..d(y*x1)] [xk d1..d(y*xk)]

Description:

Define the user-defined characters from c1 to c2.

y=3; 32≤c1≤c2≤126;

0≤x≤12; [Character A 12\*24], 0≤x≤9; [Character B 8\*16];

d=0~255; k=c2-c1+1;

y specifies the number of bytes in the vertical direction, x specifies the number of dots in the horizontal direction, d specifies the user-defined character.

ESC *		Select bit-image mode					
Format:	ASCII:	ESC	*	m	n1	n2	d1..dk
	Decimal:	27	42	m	n1	n2	d1..dk
	Hex:	1B	2A	m	n1	n2	d1..dk

Description:

Select the image mode with m; n1 and n2 specify the number of dots. The image data d1...dk

m=0, 1, 32, 33; n1=0~255; n2=0~3; d=0~255.

k=n1+256×n2 (m=0, 1)

k= (n1+256×n2) × 3 (m=32, 33)

The number of dots in horizontal direction is n1+256×n2.

If the number of dots exceeds one line, the part which exceeds the maximum number of dots (shown as below) is ignored.

M is used to select the dot image way.

M	Mode	Vertical		Horizontal	
		Number of dots	Dot density	Dot density	Number of dots (Max)
0	8-dot single-density	8	68 DPI	101 DPI	288
1	8-dot double-density	8	68 DPI	203 DPI	576
32	24-dot single-density	24	203 DPI	101 DPI	288
33	24-dot double-density	24	203 DPI	203 DPI	576

---

ESC - Turn underline mode on/off

---

Format:	ASCII:	ESC	-	n
	Decimal:	27	45	n
	Hex:	1B	2D	n

---

## Description:

n=0, 48 Turn underline mode off  
n=1, 49 Single underline mode on  
n=2, 50 Double underline mode on

---

ESC 2 Set the line spacing to 3.75mm

---

Format:	ASCII:	ESC	2
	Decimal:	27	50
	Hex:	1B	32

---

## Description:

Set the line spacing to 3.75mm.

---

ESC 3 Set the user-defined line spacing

---

Format:	ASCII:	ESC	3	n
	Decimal:	27	51	n
	Hex:	1B	33	n

---

## Description:

Set the line spacing to n\*, n=0~255.

The line spacing of TP850 printer is the n\* horizontal minimal unit.

The vertical or horizontal minimal unit is specified by GS P Command.

---

ESC = Select peripheral device

---

Format:	ASCII:	ESC	=	n
	Decimal:	27	61	n
	Hex:	1B	3D	n

---

## Description:

The Last bit of n is 0, printer disable.

The Last bit of n is 1, printer enable.

---

ESC ? Cancel user-defined character

---

Format:	ASCII:	ESC	?	n
	Decimal:	27	63	n
	Hex:	1B	3F	n

---

## Description:

Cancel the character specified by n. n=32~126.

---

ESC @ Initialize the printer

---

Format:	ASCII:	ESC	@
	Decimal:	27	64
	Hex:	1B	40

---

## Description:

Initialize the printer to the state when the printer is turned on.



ESC D					Set horizontal tab position
Format:	ASCII:	ESC	D	n1.....nk NUL	
	Decimal:	27	68	n1.....nk NUL	
	Hex:	1B	44	n1.....nk NUL	

Description:

Set the horizontal tab position to n columns from the beginning of the line.

n=0~255; k=0~32;

ESC E					Turn emphasized mode on/off
Format:	ASCII:	ESC	E	n	
	Decimal:	27	69	n	
	Hex:	1B	45	n	

Description:

When the last bit of the n is 0, the emphasized mode is turned off.

When the last bit of the n is 1, the emphasized mode is turned on.

ESC J					Print and feed paper
Format:	ASCII:	ESC	J	n	
	Decimal:	27	74	n	
	Hex:	1B	4A	n	

Description:

Print the data in input buffer and feed the paper n\* vertical minimal unit inches.

Horizontal or vertical minimal unit is specified by GS P command n=0~255

ESC M					Select English character font
Format:	ASCII:	ESC	M	n	
	Decimal:	27	77	n	
	Hex:	1B	4D	n	

Description:

n=0, 48; Character A (12\*24) is selected;

n=1, 49; Character B (8\*16) is selected.

ESC R					Select the international character set
Format:	ASCII:	ESC	R	n	
	Decimal:	27	82	n	
	Hex:	1B	52	n	

Description:

Select the international character set according to the value of n as shown below.

0: USA	1: France	2: Germany	3: U.K	4: Denmark I	5: Sweden	6: Italy
7: Spain I	8: Japan	9: Norway	10: Denmark II	11: Spain II	12: Latin America	13: Korea

ESC V					Turn 90°clockwise rotation mode on/off
Format:	ASCII:	ESC	V	n	
	Decimal:	27	86	n	
	Hex:	1B	56	n	

Description:

n=0, 48 Turn off 90°clockwise rotation mode.

n=1, 49 Turn on 90°clockwise rotation mode.

No underline effect in 90°clockwise rotation characters in underline mode.

ESC \						Set relative print position
Format:	ASCII:	ESC	\	nL	nH	
	Decimal:	27	92	nL	nH	
	Hex:	1B	5C	nL	nH	

## Description:

Set the distance between print position and current position is:  $(nL+nH*256)*$  (horizontal or vertical minimal unit). nL, nH=0~255.

Horizontal or vertical minimal unit is specified by GS P command.

ESC a n					Select justification
Format:	ASCII:	ESC	a	n	
	Decimal:	27	97	n	
	Hex:	1B	61	n	

## Description:

n=0, 48: Left justification; n=1, 49: centering; n=2, 50: right justification.

ESC c 3						Select paper sensor
Format:	ASCII:	ESC	c	3	n	
	Decimal:	27	99	51	n	
	Hex:	1B	63	33	n	

## Description:

n=xxxxxxx1B, xxxxxx1xB, xxxxxx11B, Paper near end sensor takes effect.

n=xxxxx1xxB, xxxx1xxxB, xxxx11xxB, Paper out sensor takes effect.

ESC c 4						Select paper sensor to stop printing
Format:	ASCII:	ESC	c	4	n	
	Decimal:	27	99	52	n	
	Hex:	1B	63	34	n	

## Description:

n=xxxxxxx1B, xxxxxx1xB, xxxxxx11B; Paper near end, printer stops printing.

n=xxxxx1xxB, xxxx1xxxB, xxxx11xxB; Paper out, printer stops printing.

ESC c 5						Enable/disable panel button
Format:	ASCII:	ESC	c	5	n	
	Decimal:	27	99	53	n	
	Hex:	1B	63	35	n	

## Description:

When the last bit of n is 1, disable **FEED** button to take effect.

When the last bit of n is 0, enable **FEED** button to take effect.

ESC d					Print and feed n lines
Format:	ASCII:	ESC	c	n	
	Decimal:	27	100	n	
	Hex:	1B	64	n	

## Description:

Print the data in input buffer and feed n lines, n= 0~255.

ESC p m t1 t2							Generate pulse
Format:	ASCII:	ESC	p	m	t1	t2	
	Decimal:	27	112	m	t1	t2	
	Hex:	1B	70	m	t1	t2	

Description:

Printer generates pulse, whose width specified by t1 and t2. High is t1\*2ms, low is t2\*2ms.

m=0, 48, 1, 49.

ESC t					Select code page
Format:	ASCII:	ESC	t	n	
	Decimal:	27	116	n	
	Hex:	1B	74	n	

Description:

n=0 PC437	n=1 PC932(katakana)	n=2 PC850	n=3 PC860(Portuguese)
n=4 PC863(Canadian)	n=5 PC865(Nordic)	n=6 (West Europe)	n=7 (Greek)
n=8 (Hebrew)	n=9 (East Europe)	n=10 Iran	n=15 IranII
n=16 PC1252	n=17 PC866	n=18 PC852	n=19 PC858
n=20 Thai(KU42)	n=21 Thai(TIS11)	n=22 PC1256(Arabic)	n=23 (PT151,1251)
n=24 PC747	n=25 (WPC1257)	n=26 Thai(TIS18)	n=27 Vietnam
n=28 PC864(Arabic)	n=29 PC737(Greek)	n=30 (Uigur)	n=31 (Hebrew)
n=32 PC1253(Greek)	n=33 PC775(Baltic)	n=34 Georgia	n=50 PC437(Std.Europe)
n=51 (Katakana)	n=52 PC437(Std.Europe)	n=53 PC858(Multilingual)	n=54 PC852(Latin-2)
n=55 PC860(Portuguese)	n=56 PC861(Icelandic)	n=57 PC863(Canadian)	n=58 PC865(Nordic)
n=59 PC866(Russian)	n=60 PC855(Cyrillic)	n=61 PC857(Turkish)	n=62 Hebrew
n=63 PC864(Arabic)	n=64 PC737(Greek)	n=65 PC851(Greek)	n=66 PC869(Greek)
n=67 PC928(Greek)	n=68 PC772(Lithuanian)	n=69 PC774(Lithuanian)	n=70 Thai
n=71 WPC1252(Latin-1)	n=72 WPC1250(Latin-2)	n=73 WPC1251(Cyrillic)	n=74 PC3840(Russian)
n=75 PC3841(Gost)	n=76 PC3843(Polish)	n=77 PC3844(CS2)	n=78 PC3845(Hungarian)
n=79 PC1254(Turkish)	n=80 PC3847(Brazil-ABNT)	n=81 PC3847(Brazil-ABNT)	n=82 PC1001(Arabic)
n=83 PC2001(Lithuan-KBL)	n=84 PC3001(Estonian-1)	n=85 PC3002(Estonian-2)	n=86 PC3011(Latvian-1)
n=87 PC3012(Latvian-2)	n=88 PC3021(Bulgarian)	n=89 PC3041(Maltese)	n=100 PC3846(Turkish)
n=101 WPC1255(Israel)	n=102 PC857(Tukey)	n=103 PC855(Bulgarian)	n=104 (Latvian)
n=255 Thai			

ESC {					Turn on/off upside-down printing mode
Format:	ASCII:	ESC	{	n	
	Decimal:	27	123	n	
	Hex:	1B	7B	n	

Description:

When the last bit of n is 0, upside-down printing mode is turned off.

When the last bit of n is 1, upside-down printing mode is turned on.

FS !					Select Chinese character mode
Format:	ASCII:	FS	!	n	
	Decimal:	28	33	n	
	Hex:	1C	21	n	

Description:

Bit	Off/On	Hex	Decimal	Function
0	-	-	-	Not defined
1	-	-	-	Not defined
2	Off	00	0	Double-width is not selected
	On	04	4	Double-width is selected
3	Off	00	0	Double-height is not selected
	On	08	8	Double-height is selected
4	-	-	-	Not defined
5	-	-	-	Not defined
6	-	-	-	Not defined
7	Off	00	0	Underline is not selected
	On	80	128	Underline is selected

FS & Set Chinese mode

Format:      ASCII:    FS    &  
                  Decimal:    28    38  
                  Hex:        1C    26

Description:

Enter the Chinese mode.

FS - Turn Chinese character underline mode on /off

Format:      ASCII:    FS    -    n  
                  Decimal:    28    45    n  
                  Hex:        1C    2D    n

Description:

n=0, 48 turn off the Chinese character underline mode.

n=1, 49 turn Chinese character underline mode on (one dot high).

n=2, 50 turn Chinese character underline mode on (two dots high).

Underline mode is ignored if 90°clockwise rotation is turned on at the same time.

FS . Exit Chinese mode

Format:      ASCII:    FS    .  
                  Decimal:    28    46  
                  Hex:        1C    2E

Description:

Exit Chinese mode.

FS 2 User-defined Chinese characters

Format:      ASCII:    FS    2    c1    c2    d1.....d72  
                  Decimal:    28    50    c1    c2    d1.....d72  
                  Hex:        1C    32    c1    c2    d1.....d72

Description:

c1=fe; a1≤c2≤fe; 0≤d≤255; c1 is the first code of the character; c2 is the second code of the character. Data d is arranged from top to down and then from left to right. Each lengthways column has 3 bytes and there are 24 columns in total.

FS S Set Chinese character spacing

Format:      ASCII:    FS    S    n1    n2  
                  Decimal:    28    83    n1    n2  
                  Hex:        1C    53    n1    n2

Description:

0≤n1≤255, 0≤n2≤255 Set the character left-side spacing to n1\* horizontal motion unit, right-side spacing to n2\* horizontal motion unit.

FS W Turn quadruple-size mode on/off for Chinese character

Format:	ASCII:	FS	W	n
	Decimal:	28	87	n
	Hex:	1C	57	n

Description:

0≤n≤255

When the last bit of n is 0, turn off the quadruple-size mode.

When the last bit of n is 1, turn on the quadruple-size mode.

FS p n m Print NV bit image

Format:	ASCII:	FS	p	n	m
	Decimal:	28	112	n	m
	Hex:	1C	70	n	m

Description:

1≤n≤64 m=0, 1, 2, 3, 48, 49, 50, 51 Prints the NV bit image according to the mode specified by m.

m= 0, 48 Normal printing; m=1, 49 Double width printing;

m= 2, 50 Double height printing; m=3, 51 Quadruple-size printing.

FS q n Define the NV bit image

Format:	ASCII:	FS	q	n	[xL xH yL yH d1 d2 ...dk] 1...	[xL xH yL yH d1 d2 ...dk]
	Decimal:	28	113	n	[xL xH yL yH d1 d2 ...dk] 1...	[xL xH yL yH d1 d2 ...dk]
	Hex:	1C	70	n	[xL xH yL yH d1 d2 ...dk] 1...	[xL xH yL yH d1 d2 ...dk]

Description:

1≤n≤64; xH=0; 0≤xL≤72; yH=0; 0≤yL≤30

k= (xL+xH\*256)\*(yL+yH\*256)\*8

The command can define 64 bit images at the same time. All NV images preciously defined are canceled when new bit image defined. After executing this command, ERROR LED will be on for a period of time, then the PAPER OUT LED and ERROR LED will be both on and the printer restarts. No other data or commands follow this command, or it may cause data lost or messy code. The NV image data will be stored in the printer even when printer is powered off, and will not lose till the image is redefined. In order not to damage the printer, the command should not be defined more than 10 times per day. The whole command including the bit image data should be less than 128K bytes (1M bits).

xL,xL specifies the number of bytes in the horizontal direction for the NV bit image and the limited width is 72 bytes and 576 dots.

yL,yH specifies the number of bytes in the vertical direction for the NV bit image with the height of 30 bytes and 240 dots.

d specifies the data for the NV bit image(column format).

GS BEL n1 n2 Beep for appointment

Format:	ASCII:	GS	BEL	n1	n2	n3
	Decimal:	29	7	n1	n2	n3
	Hex:	1D	07	n1	n2	n3

Description:

N1 specifies the beeping times, n2 specifies the length of beeping time and n3 specifies the length of intermission time. The unit of n1, n2 is 0.1 second.

GS !					Select Character size
Format:	ASCII:	GS	!	n	
	Decimal:	29	33	n	
	Hex:	1D	21	n	

## Description:

$n=0\sim7, 16\sim23, 32\sim39, 48\sim55, 64\sim71, 80\sim87, 96\sim103, 112\sim119$ ;

The high four bits of  $n$  represent the enlarged multiple of the character width and the low four bits represent the enlarged multiple of the character height.

GS *						Define downloaded bit image
Format:	ASCII:	GS	*	n1	n2	d1...dk
	Decimal:	29	42	n1	n2	d1...dk
	Hex:	1D	2A	n1	n2	d1...dk

## Description:


Define the downloaded bit image in the downloaded graphic area.

$n1=1\sim48, n2=1\sim255, n1\times n2<1200, k=n1\times n2\times 8$ .

$d$  specifies the bit image data.  $n1\times 8$  dots in the horizontal direction and  $n2\times 8$  dots in the vertical direction.

The downloaded bit image is valid till it is redefined or printer is restarted.

The format of bit image is shown below.



GS /					Print downloaded bit image
Format:	ASCII:	GS	/	n	
	Decimal:	29	47	n	
	Hex:	1D	2F	n	

## Description:

Print the downloaded bit image.  $n=0, 1, 2, 3, 48, 49, 50, 51$ .

$n$  is used to select the bit image. The bit image can be defined by GS \* command:

N	Mode	Density in vertical	Density in horizontal
0, 48	Normal	203 DPI	203 DPI
1, 49	Double-width	203 DPI	101 DPI
2, 50	Double-height	101 DPI	203 DPI
3, 51	Double-width and double-height	101 DPI	101 DPI

GS B					Turn white/black reverse mode on/off
Format:	ASCII:	GS	B	n	
	Decimal:	29	66	n	
	Hex:	1D	42	n	

## Description:

When the last bit of n is 0, turn the white/black reverse mode off.

When the last bit of n is 1, turn the white/black reverse mode on.

GS H					Enable/disable the printer to print HRI character
Format:	ASCII:	GS	H	n	
	Decimal:	29	72	n	
	Hex:	1D	48	n	

## Description:

n=0, 48: NO HRI printing. n=1, 49: above the barcode.

n=2, 50: above the barcode. n=3, 51: Both above and below.

GS L					Set left margin
Format:	ASCII:	GS	L	nL	nH
	Decimal:	29	76	nL	nH
	Hex:	1D	4C	nL	nH

## Description:

Set the distance between print position and left margin is  $(nL+nH*256)*(horizontal\ or\ vertical\ minimal\ unit)$ ; nL, nH=0~255.

Horizontal or vertical minimal unit is specified by GS P command.

GS P					Set horizontal or vertical minimal unit
Format:	ASCII:	GS	P	x	y
	Decimal:	29	80	x	y
	Hex:	1D	50	x	y

## Description:

Set the horizontal and vertical minimal unit to 1/x inch and 1/y inch.

When x or y=0, the default setting 1/203 inches is selected.

GS V					Select cut mode and cut paper
Format:	ASCII:	GS	V	m	(n)
	Decimal:	29	86	m	(n)
	Hex:	1D	56	m	(n)

## Description:

(The command can only realize full cut or partial cut according to the cutter type.)

m=0, 48; No n parameter, Executes a full cut.

m=1, 49; No n parameter, Executes a partial cut (with one point left in the middle).

m=6, n=0~255; Feed paper to n\*(vertical minimal unit) and executes a full cut.

m=66, n=0~255; Feed paper to n\*(vertical minimal unit) and executes a partial cut.

GS W					Set print area width
Format:	ASCII:	GS	W	nL	nH
	Decimal:	29	87	nL	nH
	Hex:	1D	57	nL	nH

## Description:

Set the print area width to  $(nL+nH*256)*(horizontal\ or\ vertical\ minimal\ unit)$ ,

nL, nH=0~255. Horizontal or vertical minimal unit is specified by GS P.

GS f

Select the HRI character font

Format:	ASCII:	GS	h	n
	Decimal:	29	102	n
	Hex:	1D	66	n

Description:

Select the HRI character when printing a bar code:

n=0, 48; Selects character A (12\*24)

n=1, 49; Selects character B (8\*16)

GS h

Set bar code height

Format:	ASCII:	GS	h	n
	Decimal:	29	104	n
	Hex:	1D	68	n

Description:

Set the height of the bar code to n dots.

n=0~255.

GS k

Print bar code

Format:	ASCII:	GS	k	m	d1..dk	NUL
	Decimal:	29	107	m	d1..dk	0
	Hex:	1D	6B	m	d1..dk	00
*	ASCII:	GS	k	m	n	d1..dn
	Decimal:	29	107	m	n	d1..dn
	Hex:	1D	6B	m	n	d1..dn

\*when m>64

m	Bar code type	Amount of data	Number of characters	Character	Character code
0	UPC-A	Fixed	11≤k≤12	0 ~ 9	48≤d≤57
1	UPC-E	Fixed	11≤k≤12	0 ~ 9	48≤d≤57
2	EAN13	Fixed	12≤k≤13	0 ~ 9	48≤d≤57
3	EAN8	Fixed	7≤k≤8	0 ~ 9	48≤d≤57
4	CODE39	Can be changed	1≤k	0 ~ 9, A ~ Z, SP, \$, %, +, -, ., / * (start, stop)	48≤d≤57, 65≤d≤90, d=32, 36, 37, 43, 45, 46, 47. d=42 (start, stop)
5	ITF	Can be changed	1≤K (even)	0 ~ 9	48≤d≤57
6	CODABAR	Can be changed	1 ≤ k	0 ~ 9, A ~ D, \$, +, -, ., /, :	48≤d≤57, 65≤d≤68, 36, 43, 45, 46, 47, 58
*65	UPC-A	Fixed	11≤n≤12	0 ~ 9	48≤d≤57
*66	UPC-E	Fixed	11≤n≤12	0 ~ 9	48≤d≤57
*67	EAN13	Fixed	12≤n≤13	0 ~ 9	48≤d≤57
*68	EAN8	Fixed	7≤n≤8	0 ~ 9	48≤d≤57
*69	CODE39	Can be changed	1≤n<255	0 ~ 9, A ~ Z, SP, \$, %, +, -, ., / * (start, stop)	48≤d≤57, 65≤d≤90d=32, 36, 37, 43, 45, 46, 47. d=42 (start, stop)



*70	ITF	Can be changed	$1 \leq n \leq 255$ (even)	0 ~ 9	$48 \leq d \leq 57$
*71	CODABAR	Can be changed	$1 \leq n \leq 255$	0 ~ 9, A ~ D, \$, +, -, ., /, :	$48 \leq d \leq 57$ , $65 \leq d \leq 68$ , 36, 43, 45, 46, 47, 58
*73	CODE128	Can be changed	$2 \leq n < 255$	NUL ~ SP (7FH)	$0 \leq d \leq 127$

GS v 0

Print raster bit image

Format:	ASCII:	GS	v	0	m	xL	xH	yL	yH	d1...dk
	Decimal:	29	118	48	m	xL	xH	yL	yH	d1...dk
	Hex:	1D	76	30	m	xL	xH	yL	yH	d1...dk

Description:

Print a raster bit image according to the numerical value of m.

m=0, 48: normal printing; m=1, 49: double width printing; m=2, 50: double height printing; m=3, 51: quadruple-size printing.

XL, xH, yL, yH=0~255.

The number of bytes in horizontal printing:  $xL + xH * 256$ ;

The number of dots in vertical printing:  $yL + yH * 256$ .

$k = (xL + xH * 256) * (yL + yH * 256)$

GS w

Set the transverse size of barcode

Format:	ASCII:	GS	w	n
	Decimal:	29	119	n
	Hex:	1D	77	n

Description:

Set the transverse size of barcode.

$2 \leq n \leq 6$ .

## Appendix Command List

Here lists the commands supported in the printer in alphabetical order.

Control command	Description
BEL	Beep once
HT	Horizontal tab
LF	Print and line feed
FF	Print and Feed paper to the next black mark position
DLE EOT	Real-time status transmission
ESC BEL	Beep for appointment
ESC SP	Set right-side character spacing
ESC !	Set print mode
ESC \$	Set absolute print position
ESC %	Select/cancel user-defined character set
ESC &	Define user-defined characters
ESC *	Select bit-image mode
ESC –	Turn underline mode on/off
ESC 2	Select line spacing to 3.75mm
ESC 3	Set line spacing
ESC =	Select peripheral device
ESC ?	Cancel user-defined character
ESC @	Initialize printer
ESC D	Set horizontal tab position
ESC E	Turn emphasized mode on/off
ESC J	Print and feed paper
ESC M	Select character font
ESC R	Select the international character set
ESC V	Turn 90°clockwise rotation mode on/off
ESC \	Set relative print position
ESC a	Select justification
ESC c 3	Select paper sensor
ESC c 4	Select paper sensor to stop printing
ESC c 5	Enable/disable panel button
ESC d	Print and feed n lines
ESC p	Generate pulse
ESC t	Select code page
ESC {	Turn on/off upside-down printing mode
FS !	Select Chinese character mode
FS &	Set Chinese mode
FS -	Turn Chinese character underline on /off

FS .	Exit Chinese mode
FS 2	User-defined Chinese characters
FS S	Set Chinese character spacing
FS W	Turn quadruple-size mode on/off for Chinese character
FS p n m	Print NV bit image
FS q n	Define the NV bit image
GS BEL	Beep for appointment
GS !	Select Character size
GS *	Define downloaded bit image
GS /	Print downloaded bit image
GS B	Turn white/black reverse mode on/off
GS H	Enable/disable the printer to print HRI character
GS L	Set left margin
GS P	Set horizontal or vertical minimal unit
GS V	Select cut mode and cut paper
GS W	Set print area width
GS f	Select the HRI character font
GS h	Set bar code height
GS k	Print bar code
GS v 0	Print raster bit image
GS w	Set the transverse size of barcode

**Jol**mark